Use alone or as a blended accelerator to achieve faster curing time performance.

1) R9 to Use as is:
   - *MXDA like properties*